



FIG.1




FIG.2




FIG.3B

FIG.3A




FIG.4B

FIG.4A





FIG. 5

The interface is divided into several sections:

- Top Bar (32):** Contains buttons for CAPTURE, FILE, VIEW, CAMERA, TOOLS, and HELP.
- Left Panel (34):**
 - CAMERA SETTING:** Includes a dropdown for CAMERA ID, buttons for RESET SETTING, CURRENT, and SAVE.
 - EXPOSURE MODE:** A dropdown menu currently set to 'A'.
 - APERTURE SCALE:** A dropdown menu currently set to 'F8'.
 - SHUTTER SPEED:** A dropdown menu currently set to '1/400'.
 - EXPOSURE COMPENSATION:** A dropdown menu currently set to '+0.3EV'.
 - ISO SPEED:** A dropdown menu currently set to '200'.
 - FLASH:** A dropdown menu currently set to 'AUTO'.
 - FOCUS:** A dropdown menu currently set to 'S_AF RELEASE PRIORITY'.
 - DRIVE:** A dropdown menu currently set to 'SINGLE'.
 - INTERVAL PHOTOGRAPHING:** A section with buttons for DETAILED SETTING and OTHER SETTING.
- Right Panel (36):**
 - CAPTURE:** A button labeled START/TERMINATION.
 - LOAD MODE:** Radio buttons for AUTOMATIC (selected) and MANUAL.
 - FOCAL LENGTH:** A field showing 'mm' and an UPDATE button.
 - PHOTOGRAPH:** A button.
- Preview Image (31):** A large central area labeled PREVIEW IMAGE: showing a waveform.
- Camera Message Area (39):** A section at the bottom of the preview area.
- Bottom Panel (40):**
 - LOAD:** A button.
 - AF/AE:** A button.
 - AF/AE & PHOTOGRAPH:** A button.
 - PHOTOGRAPHING-CONDITION SET (45):** A section containing:
 - PHOTOGRAPHING-CONDITION SET (46):** A section with a slider and buttons for MF, a zoom-in button, a zoom-out button, and an infinity button.
 - DESTINATION:** A section with a dropdown for 'C:\Documents and Settings' and a FOLDER SELECTION button.
 - File Name and Time:** Four boxes, each containing 'FILE NAME' and 'DATE AND TIME'.